

Approved Technical Dealers Only

SatFi UK+ & EU Antenna Firmware Update Process - Q3 2024

Updating Satellite Frequency Configuration File:

1. Power supply cable, antenna RF cable and IDU control panel must be connected.
2. Ensure IDU is switched off insert USB flash drive that includes **mtHWInfo.txt** configuration file into the IDU USB port.
3. Switch on the IDU.
4. Red LED should light up.
5. Green LED should flash confirming configuration file is uploading.
6. Process is complete once green LED has extinguished.
7. Finally, power down IDU and wait 10 seconds before switching IDU back on again.
8. Update process is complete.

